


Your Roku Digital Video Player



1 Inserting the Batteries in the Remote


Slide the top panel upward to open the remote. Put two AAA batteries (included) in your remote.



2

Connecting Your Player to Your TV

Make sure your TV is on and is set to display the correct video input.




3

Connecting Your Player to Your Home Network

Your player supports both wireless and wired networks. Choose the setup that is best for your network.

Wireless: Place your player within range of your wireless network.



Or

Wired: Use an Ethernet cable (not included) to connect your player to your router.



Continued >

4 Completing Guided Setup

On your TV

- Use the remote to follow the onscreen instructions.
- Once setup is complete, select a channel (such as Netflix or Amazon Video On Demand) to view, or visit the Channel Store to add more channels.
- If the channel you select requires activation, follow the onscreen instructions.



TIP:
Point your remote directly at your player.

Copyright
Copyright © 2008–2009 by Roku, Inc. All rights reserved. Roku and the Roku logo are registered trademarks of Roku, Inc. Other brand and product names are trademarks or registered trademarks of their respective holders.

FCC Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:













- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment or device.
- Connect the equipment to an outlet other than the receiver's.
- Consult a dealer or an experienced radio/TV technician for assistance.

Pursuant to Part 15.27 of the FCC Rules, any changes or modifications to this equipment not expressly approved by the manufacturer may cause harmful interference and void your authority to operate this equipment. Use of supplied data cable is required to comply with the Class B limits of Part 15 of the FCC Rules.

Microvision
This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Microvision, and is intended for home and other limited viewing uses only unless otherwise authorized by Microvision. Reverse engineering or disassembly is prohibited. U.S. Patent Nos. 3,581,936; 6,838,549; 5,515,448; 6,381,747; 6,501,842; and 7,090,698.





5 Finding Channels and Media

Finding channels

1. Press **Home** .
2. Press **Left**  or **Right**  to highlight **Channel Store**, and then press **Select** .
3. Press **Left**  or **Right**  to highlight a channel category, and then press **Down** .
4. Press **Left**  or **Right**  to highlight a channel poster, and then press **Select** .
5. Press **Down**  to highlight **Add channel**, and then press **Select** .
6. Select the new channel from your home screen and follow the onscreen instructions.

TIP:
Adding channels is a great way to customize your player. Visit the Channel Store often to find the latest channels.

Finding media

-  To go to the Home screen, press **Home**.
-  To select a channel, press **Left** or **Right** to highlight it, and then press **Select**. To select an item within a channel, press **Left** or **Right** to highlight it, and then press **Select**.
-  To return to the previous level, press **Up**.
-  To move through items a page at a time, press **Forward scan** or **Reverse scan**.



6

Playing Media

 To start or resume playing, just press **Play**.

 To stop a playback, press **Up**.

 To fast-forward, press **Forward scan** and to rewind, press **Reverse scan**. To scan faster, press the scan buttons again.

 Press **Left** or **Right** to search a video one frame at a time.



TIP:
Depending on which channel and video you're watching, you may see a series of frames when scanning. Scanning is not supported on all channels.

Getting Help



Online support

Check out these sites for web help:

- For questions on your channel account and finding media, go to your channel's website.
- For questions on setting up your digital media player, go to roku.com/support.

ROKU®



Getting Started